WP Developments 68RFE Valve Body Stud Kit Info

In this package:

- **6x Custom valve body stud**
- **6x Coated washers**
- **6x Custom 12 point nut**
- **2x Installation nut**

Install Procedure:

These stud kits are made with the customer in mind for ease of install, start one end of the threaded stud into the proper hole and finger tighten till it stops, then using the given installation nuts, you will spin one nut all the way to the end of threads on outside of the stud, you will then spin the other nut on till it is touching the first nut, use a 10MM wrench to tighten stud with the outer nut till tight. Once all 6 studs are installed, place a washer on the stud followed by the 12 point nut and snug down by hand. Torque ***COLD*, Torque to 135 inch lb.**